AIRPORT DIAGRAM

AL-416 (FAA)

TAMPA INTL (TPA)
TAMPA, FLORIDA