AIRPORT DIAGRAM

SPRINGFIELD/ CAPITAL (SPI)
SPRINGFIELD, ILLINOIS

AL-518 (FAA)



CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

RWY 4-22
S100, T200, ST175, TT350
RWY 13-31
S70, T90, ST114, TT160
RWY 18-36
S60, T70, ST89, TT130